



receiving room must **don in sequence** (a) **bouffant**, (b) surgical **mask** that covers the nose, (c) push your thumb through the seam of the sleeve of the gown, (d) put on a pair of **gloves** ensuring cuffs **overlap the gown**, then **enter** the receiving room and before handling anything, **don in sequence** (e) **moisture proof sleeves** or apron, and (f) put on a **second pair of gloves** ensuring gloves overlap sleeves and no skin is exposed.

5. **Saturate spray your sleeves and gloves** with Oxivir.
6. **Saturate spray** the interior surfaces of the receiving **biosafety cabinet** with Oxivir.
7. Saturate spray with Oxivir **only one shipping container at a time and place inside the biosafety cabinet.**
8. Saturate spray with Oxivir a sufficient number of sterile **microisolators** to receive the

8.Saturate spray witie